



# MAGELLAN

DESIGNS



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

# MAGELLAN DESIGNS

## Using Your Set-up Instructions:

The Visionary Designs Set-up Instructions for Magellan displays are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display and a logical series of detailed steps for assembly. We encourage you to study the instructions **before** attempting to assemble your exhibit.

### THIS IS VERY IMPORTANT!

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in red).

## Cleaning & Packing Your Display:

- 1) Use care when cleaning aluminum extrusions or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or counter tops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing materials. It will make re-packing much easier and will reduce the likelihood of shipping damage.

Hex Key Tool



Most visionary design exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.

Typical Connection




**Detail A:** Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.

Typical Connection




Numbered Label



**Detail B:** Each extrusion contains a numbered label that corresponds to set-up instructions. The label is located within a groove of the extrusion (when possible). Visionary Design labels contain Black numbers unless otherwise specified.

Horizontal Connection






**Detail C:** A rectangular connection bar with plastic T Knobs is inserted between two horizontal extrusions joined end-to-end. Turn the knobs clockwise to tighten. Do Not Overtighten.

**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Part	Qty	Description
1a/1b	1/1	Base Plate
2a/2b	1/1	48" Curved Vertical Extrusion
3a/3b	1/1	48" Curved Vertical Extrusion
4a/4b	1/1	46.5" Horizontal Extrusion
5a/5b	1/1	46.5" Horizontal Extrusion

Steps

- 1) Attach lower vertical extrusions [2a,3a] to base plates [1a,1b] as shown.
- 2) Attach upper vertical extrusions [2b,3b] to lower vertical extrusions [2a,3a] using connectors [a].
- 3) Connect horizontal extrusions [4a,4b & 5a,5b] using connectors [b].
- 4) Attach horizontal assemblies [4a/4b,5a/5b] between vertical assemblies as shown.
- 5) Apply graphic to assembled backwall.



**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Steps


- 1) Attach graphic header to backwall with screw caps.
- 2) Attach **back wings** to back of frame with with stand-off barrels and screw caps.
- 3) Attach side wings to A10 clamps at the sides of frame.
- 4) Lock horizontal shelf supports [6a,6b] to backwall.
- 5) Lock vertical shelf support [6] to horizontals and place counter on top.
- 6) Attach monitor count to backwall with screws.

Part	Qty	Description
6/6a/6b	1/1/1	Counter Support Extrusions


866.652.2100

**A10 Clamp Detail**

Tighten set screw to secure A10 to extrusion.



Tighten knob to secure graphic header in place.




**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

866.652.2100





Part Number	Qty	Description
7	1	39.84" Curved Vertical Extrusion
8	1	39.84" Curved Vertical Extrusion w/ A10 Clamp
9	1	39.84" Curved Vertical Extrusion w/ A10 Clamp
10	1	39.84" Curved Vertical Extrusion
11	4	17"w Horizontal Extrusion
12	3	17"w Horizontal Extrusion
12a	1	17"w Horizontal Extrusion w/ Door Stopper
13	1	17"w Horizontal Extrusion w/ Door Hinge

Steps:

- 1) Connect front and back assemblies together using horizontals [11], placing infill between verticals and horizontals.
- 2) Set internal shelf on pins where indicated. ( \* Pins)
- 3) Attach wing panel to A10 clamps as shown
- 4) Set counter top on pedestal base.




Front and Back section must remain assembled when shipping in cases




**WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING**

Top View



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

### Top View



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING